

Daily maintenance and precautions for laser cleaning machines



Proper maintenance and care can ensure the long-term stable operation and extended lifespan of laser cleaning machines. Here are several common methods for maintaining laser cleaning machines:

1. Follow the machine's power-on and power-off sequence, starting with the water cooling machine when turning on and ending with the water cooling machine when turning off.
2. Clean the laser cooling machine every half month, drain the internal dirty water, and refill with new purified water.
3. Clean the tabletop debris daily at a fixed time.
4. Use a special cleaning solution to clean the reflector and focusing lens every 6-8 hours, taking care to avoid scratching the lens.
5. Regularly clean and maintain the laser cleaning machine, including cleaning the lens, replacing the filter element, and inspecting the optical path.
6. Avoid placing the laser cleaning machine in a damp, dusty, excessively hot, or excessively cold environment, and keep the equipment dry and at an appropriate temperature.
7. Check for looseness, damage, and wear in various components of the laser cleaning machine, and adjust and replace them in a timely manner.

8. Preheat the laser cleaning machine before use to bring the equipment to its optimal working state and avoid frequent power cycling.

9. Use appropriate laser parameters, follow operational procedures and safety standards to ensure the safety of operators and equipment.

Thanks for your interesting in our laser machine !

Email: sales@jnweihua.com

Mobile & Whatsapp: +86-15853160596

